

Zoom x5 ADSL Router Configuration Instructions

Applies to: VDM/VDC

Remote Site

- ♦ Connect a PC to an Ethernet port of the Zoom ADSL/router.
- ♦ Power up Zoom ADSL/Router then the PC.
- ♦ Open Internet Explorer, type 10.0.0.2 into the address bar, press enter. Enter Username:'admin', Password:'zoomadsl'. The Zoom Web Console should now be displayed.
- ♦ Select 'Basic Setup', check that VPI, VCI and Encapsulation settings match those supplied by your service provider.
- ♦ Enter username and password, as supplied by your ISP.
- ♦ Select 'Save Changes', 'Write Settings to Flash' and 'Confirm'. The modem/router will reboot.
- ♦ A connection should now be established indicated by the Link LED on steady.
- ♦ Select 'Advanced Setup', then 'Virtual Server', (Port Forwarding).
- ♦ Enter 9221 into 'Public port' and 'Private port', select 'TCP' and 10.0.0.50 into 'Host IP Address'. Select 'Add This String'.
- ♦ 'Write settings to Flash' and 'Confirm'. The modem/router will restart.
- ♦ ADSL/Router setup complete.
- ♦ Select 'System Status' and make a note of the WAN IP address "aaa.bbb.ccc.ddd".
- ♦ It is recommended that an ADSL service with a fixed IP address is used, otherwise the WAN address may change. This WAN address is used to remotely access theVDM/VDC.
- ♦ InVDM/VDC menu, enter Network; IP Address and using camera keys enter IP address.
- ♦ Set the IP Address in theVDM/VDC to: 10.0.0.50
- ♦ Sub-net Mask in theVDM/VDC to: 255.255.255.0
- ♦ Set the Gateway in theVDM/VDC to: 10.0.0.2
- ♦ Set the Port in theVDM/VDC to: 9221
- ♦ Connect Ethernet port from Zoom ADSL/Router toVDM/VDC Ethernet port.

PC Site

- ♦ Install Vi-Viewer onto a PC which has internet access.
- ♦ Add an IP site to Vi-Viewer, specifying IP address "aaa.bbb.ccc.ddd" as above, and port 9221.
- ♦ You should now be able to connect to the remoteVDM/VDC and view images.