

Firmware upgrade instructions for Vi-Series DVR

Applies to: Vi100, Vi101, Vi200, Vi205, Vi302, Vi305, Vi400, Vi405,
Vi600, Vi605 (Vi-Series DVR)

Upgrade procedure:

- ♦ Download the ISO disc image file from <http://www.oceansystems.co.uk/FirmwareUpdates.asp> by right clicking on the link and then selecting "Save target as." Select a suitable file on your computer to save the ISO file.
- ♦ Use the free utility "ISO-Burner" from <http://www.oceansystems.co.uk/FreeSoftware.asp> to burn the ISO file onto a new CD (or use a program such as Nero, Roxio etc)
- ♦ Insert the CD into the Vi-Series DVR.
- ♦ The Vi-Series DVR will automatically ask you for confirmation to proceed with upgrade, press the OK button.
- ♦ The upgrade may require you to login because it is may be password protected.
- ♦ The screen will indicate that the Vi-Series DVR is being upgraded "Do not remove power" until programming has completed
- ♦ After the upgrade is finished the Vi-Series DVR will restart, this indicates the upgrade is complete.
- ♦ Now check that menu settings are as required.
- ♦ If Vi-Series DVR reports that replay software is not installed on one or more of the hard drives, repeat the above installation sequence.
- ♦ Also upgrade the Vi-Viewer and Vi-K2 software if a newer version is available and required, follow the support page <http://www.oceansystems.co.uk/Support.asp> for additional files.