

I can't see coverts why?

Applies to: VDC, VDM, Vi-series, M-series

- ♦If you have set coverts, only users with the sufficient access rights will be able to view them.
- ♦Access rights are set in the menu in the Passwords section
- ♦To view coverts, you must log-on by pressing the PSW key, entering the password then pressing the OK key.
- ♦As long as you have logged on and have the correct rights assigned in the menu, you will now be able to view Coverts.
- ♦When you have finished viewing the coverts, press the PSW key then the OK key to log you off. You will also automatically log off if you do not press any key for a period of time (typically 10 minutes).