

Can I connect my VDC to my network?

Applies to: VDC-4, VDC-9

If the Ethernet has been fitted in your VDC, you can access the DVR using our free viewing software which can be downloaded free from our web site:

<http://www.oceansystems.co.uk/FreeSoftware.asp>

- ◆ You can check if Ethernet is enabled by pressing and holding the ALT key then pressing the SETUP key. It will say on the screen whether Ethernet is fitted or not.
- ◆ If it Ethernet is not fitted please contact our service department. Ethernet can be retrospectively fitted to the VDC.