

How do I find the serial number?

VI-M-series: VI-M1, VI-M2, VI-M3, VI-M4

Applies to: Vi101, Vi205, Vi305, Vi405, Vi605

Vi100, Vi200, Vi302, Vi400, Vi600

VDM, VDC

CMOR Domes: VI-D118, VI-D218 etc..

To find the serial number of the unit depends on age of the product.

All units have a ratings label which is on the base of the unit, this will indicate the model and serial number of the unit.

If you have a VDM or a VDC unit press and hold the **ALT** button then press the **SETUP** button.

The serial number will now be displayed on the screen.

To go back to live images press and hold the **ALT** button then press the **SETUP** button again.

If you have an earlier Vi-Series unit Vi100, Vi200, Vi302, Vi400, Vi600 you will have an earlier style keypad, this will have an **INFO** button.

To find the serial number on this model simply press the **INFO** button and the status screen will be shown displaying the serial number and other system information.

To quit the screen press the **LIVE** button.

If you have a later Vi-Series unit Vi101, Vi205, Vi305, Vi405, Vi605 you will have an updated keypad this will have a **HELP** button and a **MON** button.

To find the serial number you need to press the **HELP** button then the **MON** button, the status screen will then be shown displaying the serial number and other system information.

To quit the screen press the **LIVE** button.

If you have an M-Series Vi-M1 unit to find the serial number press **SELECT** then use the down arrow and the right arrow to select **HELP** now select **Status/Config** with the right arrow, now select **Config** with the right arrow. The status screen should now be displayed showing the serial number.

To quit press the **ESC** button until live pictures are displayed.

If you have a M-Series Vi-M2, Vi-M3, Vi-M4 unit to find the serial number press the **HELP** button, the status screen will then be shown displaying the serial number and other system information.

To quit the screen press the **LIVE** button.

If you have a CMOR dome VI-D118, Vi-D126, Vi-D218, Vi-D226, Vi-D236 and you have a VI-K2 control keypad press **DOME** then press **MENU** you should now have a menu displayed. Use the right arrow to select **LOGIN** the serial number should now be displayed.

To quit press the **LEFT** arrow until live images are displayed.