



Zoom x5 ADSL Router Configuration Instructions

ViX05 Remote Site

- Connect a PC to an Ethernet port of the Zoom ADSL/router.
- Power up Zoom ADSL/Router then the PC.
- Open Internet Explorer, type 10.0.0.2 into the address bar, press enter. Enter Username: 'admin', Password: 'zoomadsl'. The Zoom Web Console should now be displayed.
- Select 'Basic Setup', check that VPI, VCI and Encapsulation settings match those supplied by your service provider.
- Enter username and password, as supplied by your ISP.
- Select 'Save Changes', 'Write Settings to Flash' and 'Confirm'. The modem/router will reboot.
- A connection should now be established indicated by the Link LED on steady.
- Select 'Advanced Setup', then 'Virtual Server', (Port Forwarding).
- Enter 9221 into 'Public port' and 'Private port', select 'TCP' and 10.0.0.50 into 'Host IP Address'. Select 'Add This String'.
- 'Write settings to Flash' and 'Confirm'. The modem/router will restart.
- ADSL/Router setup complete.
- Select 'System Status' and make a note of the WAN IP address "aaa.bbb.ccc.ddd".
- It is recommended that an ADSL service with a fixed IP address is used, otherwise the WAN address may change. This address is used to remotely access the ViX05.
- In VIX05 menu, enter Network; IP Address and using camera keys enter IP address.
- Set the IP Address in the ViX05 to: 10.0.0.50
- Sub-net Mask in the ViX05 to: 255.255.255.0
- Set the Gateway in the ViX05 to: 10.0.0.2
- Set the Port in the ViX05 to: 9221
- Connect Ethernet port from Zoom ADSL/Router to ViX05 Ethernet port.

PC Site

- Install Vi-Viewer onto a PC which has internet access
- Add an IP site to Vi-Viewer, specifying IP address "aaa.bbb.ccc.ddd" as above, and port 9221.
- You should now be able to connect to the remote ViX05 and view images.

Videoswitch

Ocean House	Telephone	01252-851510
Redfields Industrial Park	Fax	01252-851296
Redfields Lane	Email	sales@videoswitch.co.uk
Church Crookham	Web	www.videoswitch.co.uk
Hants GU52 0RD		