

## Upgrading Instructions VI-Series DVR

1. Download the ISO disc image file <http://www.oceansystems.co.uk/FirmwareUpdates.asp> by right clicking on the link and then selecting "Save target as." Select a suitable file on your computer to save the ISO file.
2. Use the free utility "ISO-Burner" <http://www.oceansystems.co.uk/FreeSoftware.asp> to burn the ISO file onto a new CD (or use a program such as Nero, Roxio etc )
3. Insert the CD into the DVR.
4. The DVR will automatically ask you for confirmation to proceed with upgrade – press the OK button.
5. The upgrade may require you to login because it is password protected.
6. The screen will indicate that the DVR is being upgraded "Do not remove power" until programming has completed
7. After the upgrade is finished the unit will restart, this indicates the upgrade is complete.
8. Now check that menu settings are as required.
9. If DVR reports that replay software is not installed on one or more of the hard drives, repeat the above installation sequence.
10. Also Upgrade the Vi-Connect and Vi-K2 software if a newer version is available and required.

The above procedure will work with the following VI-Series DVR's:

VI100, VI101, VI200, VI205, VI302, VI305, VI400, VI405, VI600, VI605